

KLINGER® TOP-CHEM 2000

Oxygen Service Cleaning Procedure

While wearing surgical latex gloves, the KLINGER®top-chem 2000 gaskets must first be cleaned with Trichloroethylene [79-01-6] solvent. After cleaning, gaskets must be completely dried with oil-free air. Finished gaskets shall be placed into a plastic bag marked "cleaned for oxygen service".

The ability of a gasket to make and maintain a seal depends not only on the style and quality of the gasket material, but also on medium being sealed, the flange design, the amount of pressure applied to the gasket by the bolts and how the gasket is assembled onto the flanges and tightened. These factors are beyond the manufacturer's control.

KLINGER Thermoseal

2350 Campbell Road, Sidney, Ohio 45365
Tel: +1 937 498 2222

3803 S. Sam Houston Parkway W., Houston, Texas 77053
Tel: +1 713 997 8111